
CLS TOPAZ EXPO SERIES

Manual

V1.2 - December 2024




INDEX




Index	2	Installation Bolt	5	Programming table	10
Safety information	2	Lock Position	5	Accessories	11
Content	2	Lens change	6	Accessory overview	11
Technical	3	Accessory assembly	7	List of symbols	12
Specifications	3	Dim Methods	8		
Installation Global	4	Programming	9		

SAFETY INFORMATION



CONTENT











TECHNICAL


INSTALLATION GLOBAL






























LED:	Bridgelux or Xicato	Power consumption:	Max. 15 Watt
Available colours:	CRI>90 : 2700K, 3000K, 3500K & 4000K	Housing:	Black or white coated aluminium
	CRI>98 : 2700K, 3000K, 3500K & 4000K	Weight:	780 gr
Optics:	12°, 14°, 25, 35° or 55°	IP value:	IP20
Power supply:	100 ~ 240 VAC (Roto Dim, DMX, W-DMX)	Measurements:	See drawing
	200 ~ 240 VAC (Non Dim, Local Dim)	Ambient temperature:	-10° C till +40° C
	220 ~ 240 VAC (Casambi)		













INSTALLATION BOLT


LENS CHANGE
























LOCK POSITION
















ACCESSORY ASSEMBLY

DIM METHODS





Local dimming through a potentiometer on the driver housing.



1. Place magnet on the back of the Topaz.

- Turn right or left for the desired dimming value.
- 3. Remove the magnet from the Topaz. After aprox. 3 seconds the LED will flash one time, confirming the dim value has been stored.
- 4. The magnet can also remain seated on the back of the Topaz. After aprox. 10 seconds the LED will flash one time, confirming the dim value has been stored.



Wireless (antenna)

Control by Casambi via bluetooth or Wireless DMX



7



PROGRAMMING

PROGRAMMING TABLE

Data Parameters

DMX Eunction


PROGRAMMING TABLE

Description

All settings can be configured via DMX. Settings can be configured at once or separately. When one or a couple settings needs to be changed just leave all other setting values zero. This keeps those settings unchanged. Please check the table for more information.

Always use a DMX controller with digital interface. If not available, you can purchase the CLS D-ta DMX addresser unit (#122200).

First make sure to set the DATA on the DMX controller. To program the setting into the LED fixture follow the next steps.







* If the LEDs flashes 10 times, something went wrong. Please try again. If the problem continues to occur, please contact your local sales distributor.

DIVIX	Function	Data	Parameters	Description	
CH1	Set address	0	0 = no change	Use this DMX channel to set address	
UIII	001 to 255	1255	DMX address = 1255	from 1 to 255.	
CH2	Set address	0	No change	Use this DMX channel to set address	
GHZ	256 to 508	1255	DMX address = 256508	from 256 to 508	
CH3		0	No change		
	Static behavior	1	Last DMX value	If no DMX is present the fixture will respond like set in this function.	
		2	Output off		
		3	Load static values		
CH4 CH10 CH14 CH17	Soft dim Static output	0	No change	When dynamic softdim is activated an extra DMX channel behind the colours and/or master controls the soft dim reaction. If fixed no extra DMX channe	
		1	Off		
		2	Standard		
		3	Dynamic delay		
		5-255	Fixed delay	is used. Value x delay is x*0.1 seconds, varying from 0.1-25.5 seconds.	
		0	No change	Each output channel can be set to a	
		1	Output off	static intensity.	
		2255	Intensity 2255	If no DMX is present and Static behavior is set to "load static values". The outputs will be set to the configured intensity values.	
	Load default settings	0	No change	This function resets all settings to the	
		1	Load Factory settings	Factory setting.	
	DMX control	0	No change	The intensity control of the output via	
		2	Disable	DMX can be disabled. To enable it again use RDM or power cycle with magnet in place. Wait until flash sequence and remove the magnet.	

WIRELESS DMX

See the Manual of Wireless Solutions. The Manual can be found on our CLS website, in the Downloads section. Or use the link below https://www.cls-led.com/wp-content/uploads/cls-files/W-DMX-manual.pdf


Unlink procedure

When the fixture does not receive a DMX signal (DMX controller off), place the magnet on the bottom of the fixture for 5 seconds. Slow flash indicates that the fixture is unlinked.

BLUETOOTH BY CASAMBI

For Casambi controlled fixtures, see the manual of Casambi. The Manual can be found on our CLS website, in the Downloads section. Or use the link below:

https://www.cls-led.com/wp-content/uploads/cls-products/CLS_CASAMBI/MANUAL/Manual_Casambi_controlsystem_EN.pdf







ACCESSORIES

LIST OF SYMBOLS

ACCESSORIES

Y110855	CLS 3-phase multi adapter grey XTSA 68	Y110954	CLS L-connector grey for 3-faserail, ground left
Y110865	CLS 3-phase multi adapter white XTSA 68	Y110955	CLS L-connector grey for 3-faserail, ground right
Y110875	CLS 3-phase multi adapter black XTSA 68	Y110960	CLS connect piece gray (connect rail-rail) XTS
Y110880	CLS T-connector grey for 3-phaserail, ground left	Y110961	CLS connect piece white (connect rail-rail) XTS21
Y110881	CLS T-connector black for 3-phaserail, ground left	Y110962	CLS connect piece black (connect rail-rail) XTS
Y110882	CLS T-connector white for 3-phaserail, ground left	Y110965	CLS hanging bracke for 3-phase rail, grey SKB16
		Y110966	CLS hanging set, grey SKB12 with 1.5 mtr steel
Y110925	CLS Global 3-phase rail 1mtr aluminum XTS 4100	Y110970	CLS bending tool XTSV 12
Y110926	CLS Global 3-phase rail 2 metre aluminum XTS 4200	Y110980	CLS round mountingdisk GA70 grey
Y110927	CLS Global 3-phase rail 2mtr black XTS 4200	Y110985	CLS round mountingdisk GA70 white
Y110928	CLS Global 3-phase rail 3mtr aluminum XTS 4300	Y110990	CLS round mountingdisk GA70 black
Y110929	CLS Global 3-phase rail 4mtr aluminum XTS 4100		
Y110930	CLS Global 3-phase rail 3mtr white XTS 4300	Y106601-B	CLS Topaz Expo accessory holder black
Y110931	CLS Global 3-phase rail 3mtr black XTS 4300	Y106601-W	CLS Topaz Expo accessory holder white
Y110932	CLS Global 3-phase rail 4mtr black XTS 4400	Y106603-B	CLS Topaz Expo/Zoom Snoot segment 20mm black
		Y106603-W	CLS Topaz Expo/Zoom Snoot segment 20mm white
Y110935	CLS end piece for 3-phase rail grey XTS 41	Y106604-B	CLS Topaz Expo/Zoom Barndoor black
Y110938	CLS end piece for 3-phase rail black XTS 41	Y106604-W	CLS Topaz Expo/Zoom Barndoor black
Y110939	CLS end piece for 3-phase rail white XTS 41-3	Y106605	CLS Topaz Expo filterholder
Y110945	CLS connection box for 3-phase rail, grey XTS 11	Y106606	CLSTopaz EXpo Oval beam shaper set
Y110946	CLS connection box for 3-phase rail, grey XTS 12		
Y110950	CLS connection box for 3-phase rail black XTS 11	Y106018	CLS Roto Dim magnet
Y110954	CLS L-connector grey for 3-faserail, ground left	Y106019	CLS Roto Dim magnet with keycord

ACCESSORY OVERVIEW If you want the accessories shown in the left column, you need to combine the articles marked with the 💙 Y106601-B/W Y106604-B/W Y106605 Y106607 Y106603-B/W Y106606 8 V Barndoor \checkmark 1 Honeycomb 0 Snoot \bigcirc Filter set Oval Beam set *All accessories can be combined together

	Protection class One, two or three
	Application area Indoor or outdoor
	Application area Floor, wall or ceiling
Ģ	Swivel Fixture is horizontally rotatable, indicated in degrees
$(\cdot$	Swivel Fixture is vertically rotatable, indicated in degrees
	Multiple connection Daisychain connectivity
<u>h</u>	Installation depth In centimeters
	Installation size In centimeters
Q_{ϵ}	Cable length Maximum cable attached to the fixture in centimeters
DRIVER INCLUDED EXTERNAL	Driver Inclusive or exclusive Internal or external
\square	Weight In grams/kilograms
ŢF.	Pressure Maximum pressure on the fixture in kg/cm ²
	Lifespan Of the light source in hours
	Lenses Availble lenses, indicated in degrees
$\Delta \Delta \Delta$	
	Performance Zoom Adjustable beam angle
(2)	LEDs Kind of LED used in the fixture
6 g	Plug & play Easy connection using the SmartConnect system
10,00	IP value Ingress Protection classifies the degrees of protection provided against the intrusion of the product
	Colour changing RGB, RGB-W, RGB-A, AWB or Tunable White

AWB or Tunable White

Retail & Food LED modules Clothing, furniture, kitchens, jewellery, shoes, bread, meat, fish and 0 A ¥ # 3 vegetables & fruit. -Ì Colour Available colours; \bigcirc Amber, blue, red or green White colour temperature $\bigcirc \bigcirc \bigcirc \bigcirc \bigcirc$ In different Kelvin values; Cold white, neutral white, warm white or extra warm white Curve 7 Minimal bending curve in centimeters Cutting length Indicated by the cutting marks LED pitch Pitch between the LEDs in millimeters Power supply -(=)⁺ -()-In VDC, VAC or milliAmpere Power consumption In VA or Watt Dimmable 1-10 Volt, Phase, individual, DMX dimmable or DALI PWM dimming Traditional PWM dimming, DMX analog or DMX Hybrid dim PWM DMX DMX DIM DIM DIM Bluetooth controlled 8 By Casambi CASAMBI Magno dimming M Accurate dimming from 100 - 1% by using a magnet Dynamic Control DYNAMIC POWER CONTROL DYNAMIC TEMPERATURE CONTROL Dynamic Power Control or Dynamic Temperature Control DMX input Fixture works on DMX512 protocol or Wireless DMX Combined product Compose your own fixture Warranty 3 or 5 years warranty on 3" 3 3 3" 5" the product Conformité Européenne CE CE marking for free marketability of industrial goods within the EU Energy label A A⁺ A⁺⁺

> Lightsource Equipped with a CLS, Bridgelux or a Xicato LED module



